

Technical Format for "CMT Radio Live"

MAX Receiver Channel: Stereo 3 (ID 17)
Live Feed: 7p-12mid ET
Refeed: 12mid - 5am ET

For Technical Assistance 24 hrs a day, contact 800-877-0007

The show call in number is 866-877-4268 (866-877-4-CMT)

The program can be automated through use of the Westwood One internal relay system. All in-program station commercial positions will be covered by the network. Elements marked with ">" are firm times; all others listed are approximate and the elements will float with content.

AIR TIME	RELAY	PROGRAM ELEMENT
> :59:55	-----	WARNING TONE (1kHz for one second) *****PRIOR TO HOUR 1 ONLY*****
> :00:00	-----	PROGRAM OPEN / CONTENT
:10:00	4	FLOATING STATION LINER RELAY + WINDOW (:10)
:10:10	-----	PROGRAM CONTENT
<u>FLOATING COMMERCIAL BREAK #1</u>		<u>*** TOTAL LOCAL BREAK LENGTH IS 3:10 ***</u>
:19:58	3	STATION SWEEPER WINDOW (:02)
:20:00	-----	NETWORK COMMERCIAL POSITION #1 (1:00)
:21:00	1	STATION POSITION START RELAY
:21:01	-----	STATION COMMERCIAL POSITION #1 (3:00)
:24:01	4	LINER RELAY + WINDOW (:10)
:24:12	-----	PROGRAM CONTENT
<u>FLOATING COMMERCIAL BREAK #2</u>		<u>*** TOTAL LOCAL BREAK LENGTH IS 3:10 ***</u>
:39:58	3	STATION SWEEPER WINDOW (:02)
:40:00	-----	NETWORK COMMERCIAL POSITION #2 (1:00)
:41:00	1	STATION POSITION START RELAY
:41:01	-----	STATION COMMERCIAL POSITION #2 (3:00)
:44:01	4	LINER RELAY + WINDOW (:10)
:44:12	-----	PROGRAM CONTENT
<u>FLOATING COMMERCIAL BREAK #3</u>		<u>*** TOTAL LOCAL BREAK LENGTH IS 3:10 ***</u>
:49:58	3	STATION SWEEPER WINDOW (:02)
:50:00	-----	NETWORK COMMERCIAL POSITION #3 (1:00)
:51:00	1	STATION POSITION START RELAY
:51:01	-----	STATION COMMERCIAL POSITION #3 (3:00)
:54:01	4	LINER RELAY + WINDOW (:10)
:54:12	-----	PROGRAM CONTENT
> :59:50	2	STATION ID RELAY + ID WINDOW (:10)
<i>REVISED 1.21.09</i>		